

## Synteko Extra Specifications

Under Timber Flooring or Finishes section

1. MATERIAL
  - (a) Transparent Floor Finish
    - (i) Sealer – Synteko Sealmaster 1612
    - (ii) Finish Coat – Synteko Extra1610. (20,45,90) (20 = matt, 45 = satin, 90 = semi-gloss) Minimum two coats and at least three for commercial applications.
2. SANDING
  - (a) Timber floors should be allowed to acclimatise prior to commencement of sanding
  - (b) Sweep the floors clean
  - (c) Sand the timber flooring to a smooth, even finish especially around edges to avoid 'picture frame' effect, leaving no evidence of sanding marks. Take precaution to contain dust from sanding operations.
  - (d) Patch, fill and remove all dust and apply wood filler with trowel or putty knife in accordance with manufacturer's instructions.
  - (e) Complete sanding process with 220-320 grit sanding screenback disc. This must be followed by buffing the floor with a Blue Magic pad or maroon pad to reduce wood porosity and minimise grain raise. This is critical around the edges of the room.
  - (f) Vacuum up all dust and wipe with a clean, dry towel wrapped around a push broom, until all dust is removed.
3. TRANSPARENT FINISH
  - (a) Apply the first coat of sealer immediately upon completion of sanding at recommended application rate of 12-15sqm per litre using a 9mm roller or lambswool applicator.
  - (b) Screenback sealer coat with a used 150/180 screenback, followed by buffing with a Blue Magic pad or maroon pad.
  - (c) Apply two coats of Extra (or 3 coats for commercial applications) at recommended application rate of 12-15sqm per litre (see Product Information Sheet).
  - (d) Lightly screenback between coats with a Blue Magic pad and vacuum thoroughly.
  - (e) Allow a minimum of 12 hours drying time between each coat of Best.
  - (f) On completion of final coat, the floor may be open to light traffic after 24 hours.
4. CLEANING/PROTECTING
  - (a) Minimise traffic over finished floor surface for the first 7 days. Protect finished floor surface from all construction traffic and damage.
  - (b) Provide mats at entrance doorways to provide protection to floor surface from dirt and grit.
  - (c) Do not wash floor for the first 21 days.
  - (d) Sweep and vacuum regularly and wipe up all water spills promptly. Use Synteko SuperClean to remove sticky spills and clean entire floor as required.
5. RECOATING
  - (a) Wash floor with Synteko Remover prior to screening back surface, and recoat with Synteko Extra. Wear in high traffic areas will determine when recoat is necessary.
  - (b) Apply recoat of Synteko Extra as per Product Information Sheet.